Troubleshooting Aerosole

Cause	Defect	Prevention
Spray can is held at an angle → propellant rises into the riser tube	- can "spits", throws large drops and cannot be completely emptied	- hold spray can vertically
Too much paint has been applied without intermediate flash-offs	- risk of paint runs, drips or blistering - painted surface sinks and loses gloss - full opacity may not be achieved	 spray to test apply several thin spray coats with intermediate flash-off ensure that the recommended dry film thickness is achieved
The spraying distance to the object is too far	 poor flow, "orange peel" insufficient gloss full opacity may not be achieved, colour deviation 	 spray to test, spray distance approx. 25 - 30 cm apply several thin spray coats with intermediate flash-off ensure that the recommended dry film thickness is achieved



MIPA SE · Am Oberen Moos 1 · D-84051 Essenbach · Tel.: +498703 92 20 · Fax: +498703 92 21 00 mipa@mipa-paints.com · www.mipa-paints.com

Troubleshooting Aerosole

Cause	Defect	Prevention
Spray can was not shaken long enough	 sediment of e.g. primers, fillers is not dissolved, which can lead to clogging of the dip tube pigment deposits in topcoats are not dis- solved, which can lead to colour deviation and insufficient opacity unsatisfactory spray finish and paint output due to insufficient mixing with propellant 	 shake can vigorously for at least 1 - 2 minutes before use until steel balls rattle spray to test
Overcoating of thermoplastic old paintworks	- topcoat is lifted - topcoat cracks, wrinkling	- overcoating should be avoided or insulation of the substrate with Mipa 1K-Isolator Spray
Insufficient cleaning, residues of rust, grease, oil, etc.	- poor adhesion - wetting problems - insufficient film build - rusts through quickly	 before coating, remove thoroughly rust, greases, oils, etc. from surfaces, sand slightly if necessary, apply appropriate primers
Spray can is used at too low temperatures	 unsatisfactory spray finish and output, propellant can't generate the necessary spraying pressure poor film build, insufficient flow, risk of runs 	 do not use aerosols at temperatures below +10°C allow spray cans that have been stored or transported at cooler temperatures to warm up before use

